

Oven Assembly



Be careful assembling your oven. Some of the edges are extremely sharp

1. Place the back panel on a flat surface with the bottom (bottom has larger lip) toward you.
2. Take the two side panels, handles up, and fit them inside the rim of the top plate.
3. Place side panels and top plate together on, and inside, the rim of the back panel. Fit front panel (with the large cutout hole) over the top and side panels.
4. Place the two silver heat deflectors inside against the back wall (the holes on the top end are farther from the edge than the holes on the bottom).
5. Put the four long bolts through the front panel, heat deflectors and back panel and install nuts.
6. Install the side deflectors. The holes should be at the top and the lip should be behind the long bottom bolts.
7. This is the sharpest piece, so be very careful. Bend in a little so it will fit through the front opening, then push the back of the deflector up and back so the back of the deflector is against the back top of the stove. Then, using both hands, push the front of the deflector inside the front panel and then up to the top of the oven. Once installed, push against each corner of the top deflector to make sure it is snug.
8. The wire rack with the heat shield goes on the bottom rung with the heat shield on the bottom. This shield helps to disperse the heat around the sides of the oven so the oven heats more evenly. The other wire rack can be placed on the top rung (if you need 2 shelves).
9. Install the glass in the door and hang the heat gauge behind the top of the glass on the inside of the oven. Note that the gauge is in degrees Centigrade.
10. Hang the door with long screw.
11. Install the knob on the door.